### STS-118/13A.1

### FD 04 Execute Package




MSG	Page(s)	Title
027	1 - 2	FD04 Summary Timeline (pdf)
028A	3 - 14	FD04 Flight Plan Revision (pdf)
029	15 - 16	FD04 Mission Summary (pdf)
030	17 - 19	FD04 Transfer Message (pdf)
031A		FD03 MMT Summary (pdf - Electronic Only)
032	20	O2 TANK 2 Manual Heater Operation (pdf)
033	21 - 28	New EMU Water Recharge Procedure (pdf)
026	29	Execute Package Sneakernet from ISS SSCs (pdf)

Approved by FAO: Jaime Marshik

Last Updated: Aug 11 2007 9:07AM GMT

JEDI (Joint Execute package Development and Integration), v2.04.0003



							08/11/07 05:19:10	REPLANNED
GMT β = 4 MET	08/11/07 (223) 0.95 003	23 08/12 8/00 01	01	02	03 1	04 05 05 06 07	06 07 08 08 09 10	09 10 11 12
	FD04 CDR/SUIT IV KELLY	EXERCISE POST EVA W/H20 METO		PRE SLEEP				
	PLT HOBAUGH	CWC LNCR F XFER L ML (2) U -II SI M AN	PRE P C T U	PRE SLEEP			SLEEP	
S	MS1/IV CALDWELL	IV SPPT	I	PRE SLEEP		SLEEP		
S - 1	MS2/EV1 MASTRACCHIO	CCIPCR L/N / P POST EVA W/H20 NL GR L R METOX P S R S	)	PRE SLEEP			SLEEP	
8	MS3/EV2 WILLIAMS	CCIPCR L/N/CR NLGR/P POST EVA W/H20 U RPLR METOX P SR		PRE SLEEP			SLEEP	
	MS4 MORGAN	MR P CR P IM C IS D W L EXERCISE PRE SLEEP	X T X B F A F R E G E I R U R E P F	PRE SLEEP - SHAB			SLEEP	
	MS5 DREW	P/TV   O7   PMDIS   EXERCISE	X T F A E G R U P	PRE SLEEP			SLEEP	
E	ISS CDR YURCHIKHIN	D SI	PRE LEEP DPC	PRE SLEEP			SLEEP (8.5)	
Х Р 1	FE-1 KOTOV	EXERCISE TVIS TO R L	BSA INIT DPC	PRE SLEEP			SLEEP (8.5)	
5	FE-2 ANDERSON	PCR R/P POST EVA W/H20 PLR METOX	E I	PRE SLEEP			SLEEP (8.5)	
S T S	DAY/NIGHT ORBIT W -171 TDRS E -46 Z -275	48   49	 	50		51   52	53   54	55 56
	ORB ATT SSRMS NOTES		MT BOOK D	XLATE TO WS4	,	BIAS -XLV -ZVV		. 1
	NUTES	*FILTER CK		0.10			FLT DIN/110/FLTCHT	

7	027	FD04 Summary Timeline
8	028	FD04 Flight Plan Revision
9	029	FD04 Mission Summary
10	030	FD04 Transfer Message

FD03 MMT Summary (Electronic Only) O2 TANK 2 Manual Heater Operation New EMU Water Recharge Procedure 

 1. Today's cryo config will start off with O2 tanks 1 and 4, and H2 tanks 2 and 4 in service with dual heaters. Following the start of EVA1, we will make a call to perform manual heater ops with O2 tank 2 per EPS SSR-201.

R1 CRYO O2 MANF VLV TK1 - OP (tb-OP) H2 MANF VLV TK2 - OP (tb-OP)

2. The table below summarizes the Shuttle and ISS exercise constraints for today. These constraints are also noted in your timelines for your reference.

23
24
25


Activity	Exercise Constraints			
	Shuttle	ISS		
S5 INSTALL	No exercise from S5 MANEUVER TO LOCK LAUNCH REMOVAL until 4 SOFT DOCKS ENGAGED	No exercise from S5 MANEUVER TO LOCK LAUNCH REMOVAL until 4 SOFT DOCKS ENGAGED		
EVA 1	No exercise during EVA	No unisolated exercise during EVA		
PVR RETRACT	No exercise while PVR is being retracted (EVA or motor driven)	No exercise while PVR is being retracted (EVA or motor driven)		

3. As discussed prior to flight, the Minicam can exceed the touch temperature limit during operation. Recently received data indicates that after being shut down, allowing the camera to cool for 30 minutes prior to being handled will ensure that it is below the maximum touch temperature limit.


#### MSG 028A - FD04 FLIGHT PLAN REVISION


4. In order to deconflict SSRMS motion and P6 forward radiator retraction, the maneuver to the MT translation position has been moved up slightly in the timeline. It can be executed as soon as the EV crew have completed the PVRGF relocation and given you a go to do so. If the SSRMS is in motion when the EV crew and ground are ready to retract the PVR, we will ask you to pause until the PVR retract is complete. We have one correction to robotics procedure 2.100 S5 Soft Dock Acquisition, at the end Go to {1.120 SSRMS S5 INSTALL}, steps 8 and 9 (SODF: RBT FS: S5). Go to {1.120 SSRMS S5 INSTALL}, steps 7-9 (SODF: RBT FS: S5). 5. There are no SPACEHAB viewport violations for FD04. 6. In the event of a Loss of ISS Attitude control during the S-5 Install or MT-Translate activities today, the robotics activities should be completed prior to regaining attitude control. If a Loss of ISS Attitude Control were to occur, attitude control would be regained using Russian Thrusters rather than handing over control to the Orbiter due to 7. We have uplinked two QuickTime videos of the debris impact on the Orbiter wing to the ISS SSCs. The files are located in U:\Temp\STS-118 Tile Spray Videos.







REPLANNED






















08/11/07 05:25:49







### MSG 029 (15-0903) - FD04 MISSION SUMMARY Page 1 of 2 Good Morning Endeavour! What a great day you had yesterday, first with the docking and then the S5 transfer! From down here the entire day looked "picture perfect"! Don't forget to enjoy your time docked to station! As we mentioned to you yesterday, we are planning to perform Focused Inspection on FD5. You will be happy to know that SSPTS is performing beautifully. Power transfer is right on predicts, putting us right on track for a 14+2 day mission. As we discussed pre-launch, we will be waiting a bit longer for engineering evaluations to be completed before officially stepping up to the extra days. We are ready to support your EVA today! YOUR CURRENT ORBIT IS: 186 X 182 NM NOTAMS: NOR - NORTHRUP: ALL RWYS ARE RED - WET. EDW - EDWARDS: RWY 15/33 ELS ONLY. RWY 18L NOT USABLE. WAK - WAKE ISLAND: CLOSED DUE TO RECONSTRUCTION. YYR – GOOSE BAY: RWY 08/26 CLOSED. 16/34 AVAILABLE. ZZA – ZARAGOZA: INSTALLING MOBILE NATO BARRIER. IKF - KEFLAVIK: NO AGREEMENT FOR USE. AWG – RIO GALLEGOS: NO AGREEMENT FOR USE. **NEXT 2 PLS OPPORTUNITIES:** EDW22 ORB 48 - 3/00:06 (SKC 230/15P25) EDW22 ORB 64 – 4/00:29 (SKC 230/14P24) OMS TANK FAIL CAPABILITY: L OMS FAIL: YES (SHALLOW TARGETS) R OMS FAIL: YES (SHALLOW TARGETS)

35 36

1

2 3

4

5

6 7

8 9

10

11 12

13 14

19 20

21 22

23

24 25

26

27

28

29 30

31 32

33

34

37 38

39 40

#### LEAKING OMS PRPLT BURN:

41 42

43

44

L OMS LEAK: BURN OUT-OF-PLANE AN+76 <= TIG <= AN+26 OTHERWISE BURN RETROGRADE R OMS LEAK: BURN OUT-OF-PLANE AN+77 <= TIG <= AN+26 OTHERWISE BURN RETROGRADE

45 46 47

#### **OMS QUANTITIES(%)**

R OMS OX = 44.948 LOMS OX = 45.949 FU = 46.0FU = 44.9

50 51

SUBTRACT I'CNCT COUNTER FOR CURRENT OMS QUANTITIES

#### MSG 029 (15-0903) - FD04 MISSION SUMMARY

Page 2 of 2

DELTA V AVAILABLE:

3
4
5
6

1

2

OMS 435 FPS 37 FPS ARCS (TOTAL ABOVE QTY1) TOTAL IN THE AFT 472 FPS

7 8

9

ARCS (TOTAL ABOVE QTY2) 66 FPS **34 FPS** FRCS (ABOVE QTY 1)

10 11 12

13

84 % AFT QTY 1 AFT QTY 2 46 %

> SYSTEM **FAILURE IMPACT WORK AROUND** APU 3 To reduce potential for Seal cavity drain system None. pressure decay developing fuel leakage, Drain system is leaking APU 3 will be used only N2 only; no appreciable for entry (EI-13 start). amount of fuel is Drain system pressure present. A subsequent can be monitored on fuel leak into the drain SM SYS SUMM 2, APU system has a potential 3 PMP LK P. path into the aft compartment.

24 25

26 27 28

33 34 35

36 37 38

#### MSG 030 (15-0904) - FD04 TRANSFER MESSAGE

Page 1 of 14

1 Good morning Barb, Al & Dave,

Great work yesterday – thanks very much! We've updated the Transfer List Excel file to show completed items and updated final locations. We are not asking you to update your books for any updated locations you called down to us, but you will see those updated in the Transfer List Excel file. Today's changes include the addition of another Scopemeter Temperature Probe Kit (item 431.12) to be packed by Clay per message 15-0900A.

9 For STS, the Transfer List Excel file, FD04\_TransferList\_STS118.xls, is located on the KFX machine in **C:\OCA-up\transfer**.

For ISS, the Transfer List Excel file, FD04\_TransferList\_STS118.xls, is located in **K:\OCA-up\transfer**.

15 Questions:

We didn't discuss this item yesterday, but expect that Al did this on FD1.

### Answers

 **A:** Macros in the Transfer List: In order to use these macros on the PGSCs, the macro security settings on the PGSCs need to be changed as follows:

Q: Please confirm that item 144.1 (silver bio syringes move from SH to mddk) is complete.

 Open Excel by clicking on the Start button → Programs → Microsoft Office → Microsoft Office Excel 2003 Icon.

2. Click on "Tools" > "Macro" > "Security ..."

 Note – After clicking on the **Tools** button, you may have to click on the at the bottom of the pull down menu to select Macro.

3. Click "Security Level" tab in dialog box

4. Click the "Medium" radio button.

 5. Click **OK** button and close Excel.

Note: When opening the Transfer List Excel file in C:\OCA-up\Transfer, a Security Warning window will appear - click 'Enable Macros' button.

We do not believe this setting change is required on the SSCs. However if you attempt to use the TL file on the SSC and are not given the option to enable macros when the file is opened, executing the above steps should resolve the problem.

 **A:** <u>Item 106 Coldbag</u>: You temp stowed this item on NOD104\_B2 because the locker was full. The coldbag currently in NOD104\_B2 is returning as item 706. Clay will put cold samples in this coldbag on hatch closure day. Sorry we missed this conflict....

 **A:** <u>Clay's request to not to stow any items at LAB1P6</u>. We had only planned to transfer one more item to LAB1P6 – item 11 (ODF). We've changed the final location for this item (to LAB1D6) in today's transfer list changes.

# **MSG 030 (15-0904) - FD04 TRANSFER MESSAGE** Page 2 of 14

1 2	For today - FD04 Choreography Spacehab
3	Items 102 & 105: Remove and transfer CTBS from AC03 and AC06 to ISS
	Items 113-118: Move 5MLE launched at AP01 to AC03 and transfer contents to
4	- Items 113-116. Move sivile launched at APO1 to ACO3 and transfer contents to
5	
6	<ul> <li>Items 119-122.5 (Al): Move 5MLE launched at AP04 to AP01 and transfer contents</li> </ul>
7	to ISS
8	Temp stow PWRs on MDDK for fill on FD5
9	<ul> <li>Swap wrenches in ISS IVA Toolbox in Node 1; add old ones to return bag 431</li> </ul>
10	<ul> <li>Item 132.1 (AI): Transfer EPO KIT C to MDDK for EPO video</li> </ul>
11	
12	
13	Middeck
14	<ul><li>Items 7-11: Unpack 5MLE Bag F (MD CEIL PORT 2)</li></ul>
15	<ul> <li>Transfer CHeCS 1.0 CTB for RAD deploy (ISS crew) on FD6</li> </ul>
16	<ul><li>Items 13-15: Unpack 5MLE Bag B (MD CEIL STBD 2)</li></ul>
17	<ul> <li>Retrieve Ziplock for returning IEU and temp stow in SH</li> </ul>
18	
19	
20	
21	Please update the Middeck Transfer List as follows:
22	
23	In RESUPPLY tab:
24	Make Pen and Ink update to Resupply Page 2:
25	Item 11: Update 'Stowage at Undock' to read: 'LAB1D6 rack front'
26	Replace following pages
27	Resupply Page 4
28	Resupply Page 5
29	
30	In MDDK RTN REALTIME ADDITIONS tab:
31	Replace Return Page 7
32	
33	
34	Please update the Spacehab Transfer List as follows:
35	L LAVOUTO L L
36	In LAYOUTS tab:
37	Make Pen and Ink update to Page SL-8:
38	At PF21, add "425.1 Baseplate Ballast Assembly"
39	
40	In RESUPPLY tab:
41	Replace following pages:
42	Resupply Page 17
43	Resupply Page 27
44	
45	In SWAB tab:
46	Replace Swap Page 14
47	
48	In <b>RETURN</b> tab:
49	Replace Return Page 10
50	Replace Return Page 11
51	

# **MSG 030 (15-0904) - FD04 TRANSFER MESSAGE** Page 3 of 14

For tomorrow - FD05 Choreography

2	Middeck
3 4	<ul> <li>Item 717 (Dave): Stow PMDIS CD from Dave/Alvin's PMDIS activities for return in MDDK</li> </ul>
5 6	<ul> <li>Items 701-703 (Fyodor): Stow БОК-3 items after timelined activity БОК-3 R&amp;R</li> </ul>
7	
8	Spacehab
9 10	<ul> <li>Items 119-122.5 (remaining items) (AI): Finish transferring contents of 5MLE launched at AP04 to ISS</li> </ul>
11	<ul> <li>Items 183-190: Transfer SF Rack Front items to ISS</li> </ul>
12	<ul> <li>Install ANITA locker insert; pack 3.0 CTB for return and temp stow.</li> </ul>
13 14	<ul> <li>Install ISIS dwr (save foam for returning dwr); add returning dwr/foam to prepack bag.</li> </ul>
15	<ul> <li>Transfer TVIS Skirt to ISS for FD5 R&amp;R</li> </ul>
16	<ul> <li>Items 100 &amp; 103: Remove and transfer items from AC01, AC04 to ISS</li> </ul>
17	<ul> <li>Items 124-126: (Dave) Move 5MLE launched at AS01 to AC01; and transfer</li> </ul>
18	contents to ISS
19	<ul> <li>OSE for OSE Config on FD7 (EVA 4)</li> </ul>
20	<ul> <li>Banisters (foam will be stowed in AP04 5MLE with IELK)</li> </ul>
21	<ul> <li>Items 127-129: (Dave) Move 5MLE launched at AS03 to AS01 and transfer</li> </ul>
22	contents to ISS
23	<ul> <li>OSE for OSE Config on FD7 (EVA 4)</li> </ul>
24	<ul> <li>Banisters (foam will be stowed in AP04 5MLE with IELK)</li> </ul>
25	<ul> <li>Item 627: Pack 5MLE launched at AP04 with IELK; strap at AP04</li> </ul>
26	<ul> <li>Add foam (2) from banisters in 5MLE bags</li> </ul>
27	<ul> <li>Items 632-633: Pack 5MLE launched at AP01 with coldbags; temp stow for return at</li> </ul>
28	AS01
29	<ul> <li>Item 434.31 (Fyodor): Pack old TVIS skirt for return after TVIS Skirt R&amp;R</li> </ul>
30	Item 123 (Rick or Dave): Transfer new SAFER to ISS for checkout
31	<ul> <li>Item 746 (Scott): Transfer old SAFER to SH during checkout</li> </ul>
32	
33	Diagon cell we with any greations
34	Please call us with any questions.
35 36	- The Transfer Team
37	- THE TRANSIER TEATH
38	
39	
40	
41	
42	
43	
44	
45	
46	
47	
48	
49	
50	

Manual Heater Ops Summary:

In order to complete the nominal mission duration, as well as protect an extra docked day, manual heater operations on O2 Tank 2 are required. A table showing the days where the manual operations will occur is included below for your review. Please provide comments on the plan so that it can be adjusted to accommodate any suggestions that you may have. The following times are approximate and subject to change:

Start time	1 1 3		Day's Activities	Approximate Tank QTY
02/18:30	03/04:00	4	EVA 1	98%
03/14:00	04/03:30	5	Focused Inspection	91%
05/13:00	06/03:00	7	ESP3 Unberth and Install	81%
07/12:30	08/02:00	9	Transfer, off-duty	70%
09/11:30	10/00:30	11	Transfer	61%
10/10:30	11/00:00	12	Transfer, off-duty, hatch close	54%
12/10:00	13/00:00	14	FCS C/O	44%

During manual heater ops for O2 TK2, the A (or B) heater will be cycled ON and OFF based on pressures in the tank - only one heater is used during manual heater ops in order to maximize the time between switch throws: when the tank is close to full both A and B heaters might be needed to support vehicle loads. All other O2 Cryo heaters will be turned OFF. A TMBU will be sent to set the O2 TK P upper and lower FDA limits to alert you when it is time to turn the heater OFF and ON. You will be using EPS MAL, SSR-201 CRYO HTR MANUAL OPS (pg 7-295).

See chart below for estimated times between switch throws.

Performing Manual Heater Ops on O2 TK2 causes us to deviate from our nominal O2 cryo management plan. We are still following our nominal H2 management plan.

	Heater ON (assumes single htr)	Heater OFF
TK QTY	Rise Cycle	Decay Cycle
100%	60 min	15 min
75%	15 min	30 min
65%	10 min	45 min
50%	20 min	120 min
25%	60 min	360 min

Page 1 of 8 pages

(25 Minutes) (30 Minutes if setting up CWC)

#### **OBJECTIVE:**

Recharge EMU feedwater tanks with iodinated water from EMU Water Recharge Bag Payload Water Reservoir (PWR). A small quantity is then dumped from the feedwater tanks to provide ullage for condensate collection during the next EMU prebreathe. Due to recent fill pressure issues, additional data is to be recorded and reported by the crew.

#### **INITIATE (15 MINUTES)**

MCC-H/IV **PCS**  POWERING ON UHF 1(2) RADIO

If powering on UHF 1

Perform {2.701 UHF 1 ORU ACTIVATION}, all (SODF: C&T: NOMINAL: UHF), then:

If powering on UHF 2

Perform {2.703 UHF 2 ORU ACTIVATION}, all (SODF: C&T:

NOMINAL: UHF), then:

E-Lk 2. Unstow designated EMU Water Recharge Bag (PWR) from floor bin.

#### **CAUTION**

PWRs should be inspected for gas bubbles prior to connecting them to the IRU to avoid introducing gas into the EMU feedwater tanks. If a significant quantity of gas is observed, a PWR de-gas may be required.

**PWR** 3. Unzip restraint bag to access bladder.

> In Table 0, record approximate visual quantity of H2O and gas bubbles.

Zip restraint bag closed.

A/L1F2 4. Attach bag to wall below IRU.

**IRU** 5. EMU Water Recharge Bag → ← H2O IN Port

6. √H2O outlet vlv (rotary) – CLOSED

If EMUs not powered

7. POWERING UP EMUs

7.1 √sw PWR EV-1,2 (two) – OFF  $\sqrt{PWR}$  EV-1,2 LEDs (four) – Off

√EMU O2 SUPPLY PRESS gauge: < 950

C-Lk wall 7.2 Remove SCU from stowage straps and pouches. Transfer SCU to E-Lk.

Attach with Velcro to DCM.

7.3 Remove DCM cover.

**DCM** 

UIA

Page 2 of 8 pages

7.4 SCU  $\rightarrow$  | $\leftarrow$  DCM

√SCU locked

7.5 sw POWER → BATT

#### **CAUTION**

EMU must be on BATT power when UIA suit power is turned on.

**PSA** 

7.6  $\sqrt{\text{sw}}$  SUIT SELECT (two) – OFF  $\sqrt{\text{sw}}$  EMU MODE EMU1,2 (two) – PWR

7.7 sw MAIN POWER  $\rightarrow$  ON

√MAIN POWER LED – On

7.8 sw SUIT SELECT (two) → EMU 1,2

√EMU 1,2 LEDs (two) – On √EMU 1,2 Volts: 18.0 to 19.0

UIA

7.9 sw PWR EV-1,2 (two)  $\rightarrow$  ON

√PWR EV-1,2 EMU LEDs (two) – On

DCM

7.10 sw POWER → SCU

- 8. √sw Comm FREQ LOW
- 9. sw COMM mode  $\rightarrow$  PRI

#### 10. CONFIGURE EMUS FOR CONTINUOUS EMU DATA

sw DISP → STATUS, until DATA?COMBO displayed

sw DISP → YES (hold for 2 seconds)

sw DISP → STATUS, until DATA EMU? displayed

sw DISP → YES (hold for 2 seconds)

Verify DATA?EMU displayed

sw DISP → STATUS, until H2O WP displayed

sw DISP → YES (hold for 2 seconds)

UIA 11. √WATER EV-1,2 REG vlv (two) – SUPPLY

Page 3 of 8 pages

12. WATER EV-1,2 SUPPLY vlv (two) → OPEN

If PSA Utility Outlet power being used for other applications
13. √MCC-H for verification of PSA Utility Outlet power loading

PSA 14. sw IRU/UTILITY POWER → ON

√IRU/UTILITY POWER LED – On √IRU Volts: 27.0 to 29.0

#### NOTE

- 1. The following step powers on the IRU.
- Be prepared to verify the POWER, PRESS, and TEMP LEDs briefly illuminate when IRU POWER is taken ON. As required, notify MCC-H of any missing pixels on QUANTITY display.
- IRU 15. sw POWER  $\rightarrow$  ON

√POWER, PRESS, TEMP LEDs (three) – On (at startup)

When 2.5-second LED and pixel check complete 16. √POWER LED remains – On

- 17a. sw PUMP  $\rightarrow$  ON
- 17b. **In Table 0**, record IRU Supply Pressure (NOTE: this is expected to be similar to the end of fill pressure.)
- 18a. H2O outlet vlv (rotary) ← EMU SUPPLY, start timer. In Table 0, record GMT time.

 $\sqrt{\text{PUMP LED}}$  – On (green)  $\sqrt{\text{QUANTITY display}}$  –  $\uparrow$ 

\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*

- \* If TEMP LED or PRESSURE LED On (yellow)
- \* | sw PUMP  $\rightarrow$  OFF
- \* √MCC-H

\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*

1 minute into recharge elapsed time:

18b. In Table 0, record IRU QUANTITY (NOTE: expect ~1lb)

DCM 18c. √STATUS: H2O WP

In Table 0, record EMU1 and EMU2 H2O WP

18d. As comm permits, report Table 0 data to MCC-H.

Page 4 of 8 pages

Table 0. Recharge Initiation Data

GMT / HH:MM:SS	Step 3: Bag Serial	Step 3: Appro Gas Co		Step 17b: IRU Supply	Step 18b: IRU QUANTITY	<b>Step 18c:</b> STATUS: H2O WP	
	Number	H2O (% full)	Gas (mL)	Pressure		EMU1	EMU2

#### **TERMINATE (10 MINUTES)**

DCM 19. √STATUS: H2O WP, compare with IRU Supply Pressure

If H2O WP ≤ 12.0 psi, Quantity display not ↑, and bag NOT empty

19a. Perform troubleshooting per {15-0739 EMU WATER

RECHARGE TROUBLESHOOTING} (SODF: Uplinked

Procedures: EVA)

If H2O WP  $\leq$  12.0 psi, Quantity display not  $\uparrow$ , and bag empty 19.1 sw PUMP  $\rightarrow$  OFF

19.2 H2O outlet vlv (rotary) → CLOSED

19.3 Record value from IRU Quantity display in Table 1.

Table 1. Payload Water Reservoir Content during Swap

Date	<b>Step 19.3</b> : IRU	Step 19.6: Bag Serial	Step 19.6: Approx H2O au Gas Content	
	Quantity	Number	H2O (L)	Gas (mL)

19.4 EMU Water Recharge Bag ←|→ H2O IN Port Stow in E-lk Floor Bin.

19.5 Unstow new designated EMU Water Recharge Bag.

19.6 Unzip restraint bag to access bladder.
In Table 1, record approximate visual quantity of H2O and gas bubbles
As comm permits, report Table 1 data to MCC-H.

Zip restraint bag closed.

19.7 EMU Water Recharge Bag  $\rightarrow$  | $\leftarrow$  H2O IN Port

IRU

E-lk

IRU 23 JUL 07

Page 5 of 8 pages

19.8 Go to step 17.

When H2O WP > 12.0 psi, stable for ~30 seconds, and Quantity display not ↑ (charging complete)

IRU 20a. In Table 2, record Supply Pressure gauge reading

DCM 20b. VSTATUS: H2O WP, compare with IRU Supply Pressure In Table 2, record EMU1 and EMU2 H2O WP

UIA 20c. WATER EV-1,2 SUPPLY vlv (two) → CLOSE

IRU 21. sw PUMP → OFF

√PUMP LED – Off

- 22. H2O outlet vlv (rotary) → CLOSED.
- 23. In Table 2, record value from Quantity display.
- 24. sw POWER → OFF

√POWER LED – Off

25. EMU Water Recharge Bag ←|→ H2O IN Port

Unzip restraint and inspect bag for water and gas content. Record on **Table 2**.

Zip restraint bag closed.

26. As comm permits, report Table 2 data to MCC-H.

Table 2. Recharge Termination Data

Date	Step 20a: IRU	•	Step 20b: STATUS: H2O WP		Step 23: Bag	<b>Step 25:</b> Approx H2O and Gas Content	
	Supply P	EMU1	EMU2	QUANTITY	Serial #	H2O (% full)	Gas (mL)

A/L1D1 27. Stow bag in floor bin.

As comm permits, report new stowage location to MCC-H.

If PSA Utility Outlet power not being used for other applications

PSA 28. sw IRU/UTILITY POWER → OFF

√IRU/UTILITY POWER LED – Off

23 JUL 07

Page 6 of 8 pages

UIA

### 29. <u>SETTING UP EMU WASTEWATER COLLECTION BAG</u> (5 MINUTES)

29.1 Unstow the following

CWC s/n \_\_\_\_ (Waste Water)

☐ Yellow Red QD adapters (2)

☐ Blue Blue Hose

#### If required

29.2 Yellow Red QD (2)  $\rightarrow$  | $\leftarrow$  Blue Blue Hose (one each end)

29.3 Yellow Red QD → |← CWC

29.4 Yellow Red QD → |← Waste Water Port Refer to Figure 1 for CWC attachment configuration.



Figure 1.- CWC connected to UIA Waste Water Port.

EMU 30.  $\sqrt{\text{Helmet}} \leftarrow | \rightarrow \text{HUT}$ 

Install SCOF.

√SCOF locked

DCM 31. O2 ACT  $\rightarrow$  IV

UIA 32. √WATER EV-1(2) SUPPLY vIv – CLOSE

#### NOTE

Be prepared to start a 30-second timer for the ullage dump. Steps 33 and 34 should be performed serially for EMU 1 and EMU 2.

33. WATER EV-1(2) REG vlv → WASTE

Wait 30 seconds.

34. WATER EV-1(2) REG vlv → SUPPLY

23 JUL 07

Page 7 of 8 pages

35. Repeat steps 33 and 34 for other EMU.

DCM 36. O2 ACT → OFF

UIA 37. Yellow Red QD ←|→Waste Water Port

38. Yellow Red QD ←|→CWC

39. Install UIA Waste Water Port Cap

40. Restow CWC, Blue Blue Hose with Yellow Red QDs.

EMU 41. Remove SCOF.
Stow SCOF in EMU Equipment Bag.

DCM 42. sw COMM mode → OFF

43. As required per timeline, go to {1.240 POST EVA} (SODF: ISS EVA SYS: EVA PREP/POST).

or

Go to {1.525 LCVG WATER FILL} (SODF: ISS EVA SYS: EMU MAINTENANCE).

or

Go to step 44.

44. POWERING DOWN EMUs (AS REQUIRED)

DCM 44.1 √sw POWER – SCU

UIA 44.2 sw PWR EV-1,2 (two)  $\rightarrow$  OFF

√PWR EV-1,2 LEDs (four) – Off √PWR EV-1,2 VOLTS: ~00.0

44.3 OXYGEN EMU 1,2 vlv (two) → CLOSE

PSA 44.4 sw SUIT SELECT (two)  $\rightarrow$  OFF

√SUIT SELECT LEDs (four) – Off

44.5 sw MAIN POWER → OFF

√MAIN POWER LED – Off

DCM 44.6 SCU  $\leftarrow \mid \rightarrow$  DCM

44.7 Install DCM cover.

Page 8 of 8 pages

C-lk wall 44.8 Insert SCU in stowage pouch.

MCC-H/IV

45. POWERING DOWN UHF 1(2)

PCS

If powering off UHF 1
Go to {2.702 UHF 1 ORU DEACTIVATION}, all (SODF: C&T: NOMINAL: UHF).

If powering off UHF 2

Go to {2.704 UHF 2 ORU DEACTIVATION}, all (SODF: C&T:

NOMINAL: UHF).

### MSG 026 (15-0902) - EXECUTE PACKAGE SNEAKERNET FROM ISS SSCS Page 1 of 1

The following procedure should be followed on MCC "Go" to perform a sneakernet transfer of execute package messages from the ISS SSCs to the Shuttle PGSCs. During the docked timeframe, the Shuttle Ku coverage is very limited in the hours before crew wakeup due to ISS blockage. The Shuttle OCA OFFICER will uplink the Shuttle execute package to a Shuttle PCMCIA card (inserted into an ISS SSC) and you (shuttle crew) will move the PCMCIA card to a Shuttle PGSC in the morning and run a batch file to copy the execute package files to their standard location on the KFX PGSC.

#### Prior to Sleep,

- 1. Insert a Shuttle "Late Update" PCMCIA card into an ISS SSC (SSC 4 or 6 should be fine, but coordinate with the ISS crew).
- 2. Verify that KFX is running on that SSC.
- 3. Inform the MCC which SSC was used.

#### During sleep,

The MCC will uplink the execute package files to the PCMCIA card in the SSC

#### At Wakeup,

- 1. Remove the "Late Update" PCMCIA card from the SSC in the ISS
- 2. Insert the "Late Update" PCMCIA card into the KFX PGSC in the Shuttle
- On the KFX PGSC Desktop, double click the "DistributeShuttleUplink.bat" icon.
  This will copy all of the files from the PCMCIA card to the correct folders on the
  KFX PGSC.
- 4. On the KFX Desktop, double click the "Ex Pkg # 2" shortcut to initiate the printing of the messages.